

TIME CHANGE FOR NEAX 2000 IVS

1. FROM ANY DISPLAY PHONE PRESS FNC THEN CONF THEN THE *(STAR KEY).
2. PRESS FNC THEN CONF AND THE # (POUND KEY).
3. THE LCD SCREEN WILL SHOW "CAT MODE", PRESS LNR/SPD.(Redial)
4. THE LCD SCREEN WILL SHOW "COMMAND=", DIAL 02 THEN RECALL.
5. DIAL 2 THEN RECALL
6. DIAL THE TIME IN MILITARY FORMAT WITH SIX DIGITS, THEN CONF. *

NOTE: Hour, Minute, and Second are set by two digits in each order named. Hour information is set in 24-hour clock format. (2 pm = 140000)

7. LIFT THE HANDSET OFF CRADLE AND REPLACE ON CRADLE.
8. TIME CHANGE COMPLETE. THIS WILL CHANGE THE TIME ON ALL PHONES.

SPECIAL NOTE: If after you press the CONF Key, you see appear on the display 'CODE NOT USED' enter the following procedure. THEN begin at step 3 again.

- A. PRESS LNR/SPD (REDIAL) KEY. (You will see COMMAND=)
- B. DIAL 03 ON THE DIAL PAD, PRESS THE RECALL KEY. (You will see 03>)
- C. DIAL 7 AND PRESS THE RECALL KEY. (You will see 03>7:--)
- D. DIAL " your phone system password " PRESS CONF.
- E. It should read OK on the bottom of the screen. Done.
- F. Continue with step 3 at the beginning of this page.

ANY QUESTIONS FEEL FREE TO REACH US AT (626) 582-7088